

Item #	Description
283-0005	6-32 X 1/2 18-8 SS BUTTON SOC CS
283-0007	6-32 X 3/4 18-8 SS BUTTON SOC CS
283-0104	8-32 X 3/8 18-8 SS BUTTON SOC CS
283-0105	8-32 X 1/2 18-8 SS BUTTON SOC CS
283-0107	8-32 X 3/4 18-8 SS BUTTON SOC CS
283-0110	8-32 X 1 18-8 SS BUTTON SOC CS
283-0206	10-24 X 1/2 18-8 SS BUTTON SOC CS
283-0207	10-24 X 5/8 18-8 SS BUTTON SOC CS
283-0208	10-24 X 3/4 18-8 SS BUTTON SOC CS
283-0210	10-24 X 1 18-8 SS BUTTON SOC CS
283-0212	10-24 X 1-1/4 18-8 SS BUTTON SOC CS
283-0215	10-24 X 1-1/2 18-8 SS BUTTON SOC CS
283-0220	10-24 X 2 18-8 SS BUTTON SOC CS
283-0305	10-32 X 3/8 18-8 SS BUTTON SOC CS
283-0306	10-32 X 1/2 18-8 SS BUTTON SOC CS
283-0307	10-32 X 5/8 18-8 SS BUTTON SOC CS
283-0308	10-32 X 3/4 18-8 SS BUTTON SOC CS
283-0310	10-32 X 1 18-8 SS BUTTON SOC CS
283-0312	10-32 X 1-1/4 18-8 SS BUTTON SOC CS
283-0315	10-32 X 1-1/2 18-8 SS BUTTON SOC CS
283-0320	10-32 X 2 18-8 SS BUTTON SOC CS
283-0406	1/4-20 X 1/2 18-8 SS BUTTON SOC CS
283-0407	1/4-20 X 5/8 18-8 SS BUTTON SOC CS
283-0408	1/4-20 X 3/4 18-8 SS BUTTON SOC CS
283-0410	1/4-20 X 1 18-8 SS BUTTON SOC CS
283-0412	1/4-20 X 1 1/4 18-8 SS BUTTON SOC CS
283-0415	1/4-20 X 1-1/2 18-8 SS BUTTON SOC CS
283-0417	1/4-20 X 1-3/4 18-8 SS BUTTON SOC CS
283-0420	1/4-20 X 2 18-8 SS BUTTON SOC CS
283-0425	1/4-20 X 2-1/2 18-8 SS BUTTON SOC CS
283-0430	1/4-20 X 3 18-8 SS BUTTON SOC CS
283-0506	5/16-18 X 1/2 18-8 SS BUTTON SOC CS
283-0507	5/16-18 X 5/8 18-8 SS BUTTON SOC CS
283-0508	5/16-18 X 3/4 18-8 SS BUTTON SOC CS
283-0510	5/16-18 X 1 18-8 SS BUTTON SOC CS
283-0512	5/16-18 X 1-1/4 18-8 SS BUTTON SOC CS
283-0515	5/16-18 X 1-1/2 18-8 SS BUTTON SOC CS
283-0517	5/16-18 X 1-3/4 18-8 SS BUTTON SOC CS
283-0520	5/16-18 X 2 18-8 SS BUTTON SOC CS
283-0525	5/16-18 X 2-1/2 18-8 SS BUTTON SOC CS
283-0530	5/16-18 X 3 18-8 SS BUTTON SOC CS
283-0607	3/8-16 X 3/4 18-8 SS BUTTON SOC CS
283-0610	3/8-16 X 1 18-8 SS BUTTON SOC CS
283-0612	3/8-16 X 1-1/4 18-8 SS BUTTON SOC CS
283-0615	3/8-16 X 1-1/2 18-8 SS BUTTON SOC CS
283-0617	3/8-16 X 1-3/4 18-8 SS BUTTON SOC CS
283-0620	3/8-16 X 2 18-8 SS BUTTON SOC CS
283-0625	3/8-16 X 2-1/2 18-8 SS BUTTON SOC CS
283-0630	3/8-16 X 3 18-8 SS BUTTON SOC CS
283-0807	1/2-13 X 3/4 18-8 SS BUTTON SOC CS
283-0810	1/2-13 X 1 18-8 SS BUTTON SOC CS
283-0812	1/2-13 X 1-1/4 18-8 SS BUTTON SOC CS
283-0815	1/2-13 X 1-1/2 18-8 SS BUTTON SOC CS
283-0817	1/2-13 X 1-3/4 18-8 SS BUTTON SOC CS
283-0820	1/2-13 X 2 18-8 SS BUTTON SOC CS
283-0825	1/2-13 X 2-1/2 18-8 SS BUTTON SOC CS
283-0830	1/2-13 X 3 18-8 SS BUTTON SOC CS
284-0405	1/4-28 X 1/2 18-8 SS BUTTON SOC CS
284-0407	1/4-28 X 3/4 18-8 SS BUTTON SOC CS
284-0410	1/4-28 X 1 18-8 SS BUTTON SOC CS

284-0412	1/4-28 X 1-1/4 18-8 SS BUTTON SOC CS
284-0415	1/4-28 X 1-1/2 18-8 SS BUTTON SOC CS
284-0507	5/16-24 X 3/4 18-8 SS BUTTON SOC CS
284-0510	5/16-24 X 1 18-8 SS BUTTON SOC CS
284-0512	5/16-24 X 1-1/4 18-8 SS BUTTON SOC CS
284-0515	5/16-24 X 1-1/2 18-8 SS BUTTON SOC CS
284-0607	3/8-24 X 3/4 18-8 SS BUTTON SOC CS
284-0610	3/8-24 X 1 18-8 SS BUTTON SOC CS
284-0615	3/8-24 X 1-1/2 18-8 SS BUTTON SOC CS