

BATTERY MASTER DISCONNECT SWITCHES

SPST 6-36V, 180 AMP CONTINUOUS, 1000 AMP IN RUSH, 2 STUD TERMINALS



51-302 SPST 2 POSITION
OFF-ON
6-36V
2 STUD TERMINALS



51-915 SPST 2 POSITION
OFF-ON
6-36V
2 STUD TERMINALS
.25 ANTI-ROTATION
INDEXING POST



51-316 SPST 2 POSITION
OFF-ON
6-36V
2 STUD TERMINALS
2 REMOVABLE KEYS

DPST 6-36V, 180 AMP CONTINUOUS, 1000 AMP IN RUSH. 4 STUD TERMINALS




51-904 DPST 2 POSITION
OFF-ON
4 STUD TERMINALS


SPECIALITY STARTER SWITCHES



52-800 3 POSITION ON-OFF
-ON
50 AMP @ 12V
REVERSING SWITCH



51-303 FOR USE W/POLLAK
51-302, 51-904



51-322 FOR USE W/POLLAK
51-915, 51-916

BATTERY MASTER DISCONNECT SWITCHES CONT.



854-0247 RATED 500 AMP CONTINUOUS
5000 AMP SURGE @ 12V
WATER RESISTANT



31-619 3 POSITION
OFF-BAT 1-BAT 2
**KEYED BATTERY SELECTOR
SWITCH**



854-0279 200 AMP CONTINUOUS @
12V
1000 AMP FOR 5 SECONDS



854-0395 RATED 200 AMP CONTINUOUS
1000 AMP PEAK
**AUTOMATIC/WIRELESS
INCLUDES 2 KEY FOBs**



854-0360 4 POSITION BOTH/1/2/OFF
6-36V
CONTINUOUS RATING 310
AMP
INTERMITTENT RATING 500
AMP FOR 5 SECONDS
**DISCONNECT/SELECTOR
SWITCH**



854-0405 500 AMP SURGE @ 12V
RATED 100 AMP CONTINUOUS
250 AMP SURGE @ 24V
RATED 50 AMP CONTINUOUS
WATER RESISTANT



854-0387 2 POSITION
CRANK RATING 700 AMP/10
SECONDS
CONTINUOUS RATING 300
AMP
INTERMITTENT RATING 1000
AMP/5 SECONDS
APPLICATION UP TO 48V



854-0406 FOR USE W/854-0405
WATER RESISTANT



853-2020 QUICK DISCONNECT BATTERY
SWITCH
RATED 500 AMP SURGE AND
125 AMP CONTINUOUS AT 12V
**INSTALL ON NEGATIVE
BATTERY POST ONLY**



854-0393 4 POSITION
CRANK RATING 700 AMP/10
SECONDS
CONTINUOUS RATING 300
AMP
INTERMITTENT RATING 1000
AMP/5 SECONDS
APPLICATION UP TO 48V



854-0138 5/8" DIAMETER POST FOR
RECEIVING STANDARD BATTERY
CLAMP
MOUNT ON **NEGATIVE** BATTERY
POST TO DISCONNECT GROUND
AND BATTERY

2531 E. JENSEN
FRESNO, CA. 93706



(559) 485-2658
mail@frontierfastener.com

BATTERY MASTER DISCONNECT SWITCHES CONT.



854-0148 MOUNT ON **NEGATIVE**
BATTERY POST TO DIS-
CONNECT GROUND AND
BATTERY



854-0188 MOUNT ON **NEGATIVE**
BATTERY POST TO DIS-
CONNECT GROUND
AND BATTERY
REMOTE SURFACE
MOUNT